

Page 1 of 3

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE FITTING THIS KIT If you have a problem, however small, call our Technical Department

Tel:- 01925 636950. Fax:- 01925 418948. Monday to Friday 9am - 5pm







2 Fit the metal tube into the end of the original air intake hose. Slide the studded hose clip onto the intake hose feed the stud through the hole in the bracket. Fit the flat washer then spring washer and nut to the stud (see drawing C for further detail). Align the intake hose ensuring that it is clear of the top pulley. Once aligned, firmly tighten the thermostat bolt and the nut on the

(3) Fit the filter onto the end of the metal tube up to the step in the filter base. Do not push in beyond the step as this will affect air flow. Tighten the clip until the filter just turns then rotate the filter until the K&N logo is straight then tighten the clip one full turn (360 degrees) no more.

4 Push the plastic tube half way into the end of the brake servo pump breather hose and secure with the small hose clip. Feed the plastic tube into the hole



Lengthen the flexi cold air hose to 51cm / 20". Feed the cold air hose down between the gearbox and radiator to the front lower bumper. Use a long plastic tie to attach the top of the cold air to the coolant hose



Tuning.

CAT. Cars No adjustments required

An increase in fuel mixture may be required if further modifications are carried out.

Filter Maintenance.

Under normal conditions clean and reoil the filter at approx. 40,000 miles / 65,000km.

Use only K&N cleaner and oil and follow the instructions carefully.

K&N filters are pre-oiled ready to fit

The advantage of K&N's cold air intake system.

Cooler air being denser, will show positive improvements in power over filter systems that draw hot air from the engine bay.

This Kit Should Contain:

- 1 x Clamp On Filter
- 1 x Metal Tube
- 1x Cold Air Hose Assembly
- 1 x Instruction Sheet
- 1 x Instruction Pack
 - 1 x Filter Maintenance Sheet
 - 1 x K&N window sticker
 - 1 x Million Mile sticker
 - 1 x Million Mile Warranty
- 1 x Fixing Kit:-
 - 1 x #12 Hose clip
 - 1 x Studded Hose clip
 - 1 x M6 Nut
 - 1 x M6 Washer
 - 1 x 6mm Spring Washer
 - 1 x Long Cable Tie
 - 1 x Medium Cable Tie
 - 1 x #44 Hose Clip.
 - 1 x Plastic Tube
 - 1 x Bracket

FITTING YOUR OWN 57i KIT

If not it is essential that the person fitting the kit (e.g. mechanic carefully follows these particular instructions even if he has fitted K&N kits before. This will save you both time and money. kits incorrectly fitted may show a loss in performance e.g. the positioning of the essential cold air hose, (flexi expandable and rubber hoses are used).

A final check under the bonnet, by yourself with the instructions, would seem sensible