



Part Number 57-0581 INSTALLATION INSTRUCTIONS

Skoda Fabia vRS 1.9L TDi 130bhp 2003...

1. Disconnect the negative terminal from the vehicle battery.
2. Unclip and remove the electrical harness plug from the MAS (Mass Air Sensor). (Fig. 1)
3. Unclip and remove the intake hose from the MAS. (Fig. 2)
4. Remove the APC (Air Pressure Control) valve hose from the air box lid. (Fig. 3)
5. Remove the air box feed pipe from the scoop located on the slam panel. (Fig. 4)
6. Undo the air box mounting bolt & remove the complete air box assembly from the vehicle. (Fig. 5&6)
7. Unscrew & remove the scoop from the slam panel. (Fig. 7)
8. Assemble the saddle bracket / mounting bracket using the hardware supplied. (Fig.8)
9. Unbolt & remove the rear gearbox-mounting bolt. Position the 2 large flat washers either side of the large hole on the new mounting bracket & secure the bracket assembly to the gearbox mounting using the M10 bolt supplied. (Fig. 9&10)
10. Unscrew & carefully remove the MAS from the air box assembly. (Fig.11&12)
11. Fit the rubber filter adaptor onto the MAS. (Fig.13)
12. Refit the MAS into the intake hose and secure using the original clip. (Fig.14)
13. Place the rubber filter adaptor / MAS onto the saddle bracket assembly. Fit the #64 hose clip around the saddle bracket / filter adaptor, do not tighten at this time. (Fig.15)
14. Fit the air filter onto the filter adaptor / saddle bracket & now tighten the #64 hose clip supplied (Ensure the clip secures the air filter assembly to the saddle bracket). (Fig.16&17)
15. Reconnect the electrical harness plug to the MAS. (Fig.18)
16. Fit the barbed adaptors into each end of the new silicone hose as shown. (Fig. 19)
17. Join the new silicone hose assembly to the APC valve hose as shown. (Fig.20)
18. Insert the other end of the silicone hose into the hole in the base of the air filter. (Fig.21)
19. Carefully expand the flexi cold air hose. Feed the hose into the vent in the slam panel & secure using a plastic tie supplied. (Fig.22)
20. Position the other end of the hose to finish approx. 4" / 10cm from the air filter & secure using a plastic tie supplied. (Fig.23)
21. Reconnect the negative battery terminal.
22. Carry out a final check of the height / alignment of the K&N induction system before starting the engine. Installation is now complete.

Parts list:

- 1 x Air filter Element.
- 1 x Rubber Filter Adaptor.
- 1 x Flexi Cold Air Hose.
- 1 x Literature Pack.

Fixing Kit :-

- 1 x 'Z' Mounting Bracket.
- 1 x Saddle Bracket.
- 1 x M6 Flat Washer.
- 1 x M6 Nylock Nut.
- 1 x M6 C'sunk Bolt.
- 1 x Nylon Conical Washer.
- 2 x Large Flat Washer.
- 3 x Plastic Tie.
- 1 x M10 Hex Head Bolt.
- 1 x #64 Hose Clamp.
- 1 x Silicone Hose.
- 2 x Barbed Hose Adaptor.

WARNING: Before starting the engine carry out a final fitment check of the K&N performance kit. It will be necessary for all intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void the warranty.



Fig. # 1



Fig. # 2



Fig. # 3



Fig. # 4



Fig. # 5



Fig. # 6



Fig. # 7



Fig. # 8




Fig. # 9



Fig. # 10



Fig. # 11



Fig. # 12



Part Number 57-0581 INSTALLATION INSTRUCTIONS

Skoda Fabia vRS 1.9L TDi 130bhp 2003...



Fig. # 13



Fig. # 14



Fig. # 15



Fig. # 16



Fig. # 17



Fig. # 18



Fig. # 19



Fig. # 20



Fig. # 21



Fig. # 22



Fig. # 23